





Iso™ Technical Specification

Paper Holder

DN0708

Dimensions: Stock Numbers: DN0708BN Lifetime limited warranty against leaks, drips and finish defects to the original consumer purchaser Brush Nickeb warranty if used in commercial installations 3-Function Showerhead 3 | | Models: 3233EP series [78.875] DN0708CH - Paper Holder Chrome Finish **Installation Instructions: Materials:** Directions below are for installation into drywall. If installing product into a Paper Holder is constructed of zinc. stud, use the wood screws only. 1/ Position the mounting template on the wall in the desired location. . Using a level, align the template and tape it to the wall. 3. Drill two 5/16" holes as indicated on the template 4. Remove the template from the wall, 5. Fold ends of the plastic toggle together and insert into each hole in the wall. 6. Lightly tap anchors until flush with the wall. 7. One at a time, insert plastic in into each of the anchors and lightly tap to activate anchor. Remove pin and repeat on all anchors.

facing you.

Rev. 2/11

11. Place each ass®en®ly⊆ber the mounting posts with the setscrews facing down. Pivoting posts with bar should be on the left side. Tighten both setscrews

8. Remove mounting of sts from the product as semblies by loosening each set 9. Place the mounting plate on the wall over the installed wall anchors with "UP"

10. Insert screws through the mounting plate into the anchors. Tighten the screws.

FOR MORE INFORMATION CALL: 1-800-BUY-MOEN

www.moen.com



1/34/2012 aleued 00