


■ Order by Part Number


Stopper - Plastic
186589



Removable Splash Guard
1016



Sink Flange - Polished Stainless
1017



Mounting Assembly Kit - 1824

Fiber Gasket

Backup Flange


Screws (x3)

Mounting Ring

Snap Ring

Cushion Mount

Lower Mounting Ring




Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow



Replacement Power Cord Kit
1024



Garbage Disposals

MODEL GXP50c

Other Available Accessories




Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit	
Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

Optional:

Dishwasher Connector Kit
1023



Unjamming Wrench
1037

