






# Illustrated Parts

## Order by Part Number



**Mounting Assembly Kit - 1824**

Fiber Gasket

Backup Flange

Screws (x3)

Mounting Ring

Snap Ring

Cushion Mount


Lower Mounting Ring

**Drain Elbow Kit - 1026**

Rubber Gasket

Screws

Drain Elbow



**Garbage Disposals**

**MODEL** GXS75c

**Other Available Accessories**

**Air Switch Remote Controller**

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit	
Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

**Optional:**

Dishwasher Connector Kit  
1023

Unjamming Wrench  
1037