

TruFlush Flushometer TRF 8196-0.5

Code Number

3400102

Description

Concealed, sensor-activated, hardwired or battery-powered, piston type, rough brass, true flushometer for top inlet or rear inlet urinals. Includes ability to power via hardwire.

▶ Flush Cycle

0.5 gpf/1.9 Lpf

▶ Specifications


Quiet, concealed piston type sensor-activated, battery-powered (or hardwired) flushometer with the following features:

- Piston color-coded by flush volume for easy identification
- High Efficiency flush volume for water conservation
- Self-adaptive Infrared Sensor with Lobular Sensing Fields for accurate target detection
- Latching Solenoid Operator
- Electronic Courtesy Flush® Override Button
- Four (4) Size AA alkaline Batteries included
- "Low Battery" Flashing LED
- Ability to hardwire with battery backup
- Initial target detection Indicator Light (first 10 minutes)
- Flood prevention feature limits flow to a trickle in wide open position
- Heavy duty brass valve body
- Safety collar locks activation assembly to prevent access of internal components without shutting off water
- Replaceable piston assembly, accessible by removing front wall plate
- Concealed shut off sleeve adjusts flow rate
- Operating pressure 10-100 psi (0.7-7 bars)
- 1-1/2" NPT (female) Inlet standard
- 1-1/2" NPSM Outlet standard
- Chrome-plated, corrosion-resistant, vandal resistant wall plate
- Fixed Volume Piston with Filtered O-ring Bypass

Variations

- M = Zinc die cast wall plate TRF 8196-0.5-M (3400107)
- Inlet adaptor variations
 - Specify 1.25" (31.75 mm), 1" (25.4 mm) or .75" (19.1 mm)
 - Available with NPT or BSP-G threads
- Various flush connection pipe sizes available- consult local Sloan rep or factory
- Vacuum breaker- (specify tube length)- required for ASSE 1037 compliance







Wall plate dimensions 6" x 6" (152 mm x 152 mm)

Automatic Operation

The self-adaptive infrared sensor sets the flushing mechanism when the user is detected and completes the flush when the user steps away.

▶ Hygienic

Touchless, sensor activation eliminates the need for user contact to help control the spread of infectious diseases.

► Compliance & Certifications











TruFlush Flushometer TRF 8196-0.5

Electrical Specifications

- 6 VDC Input 4 AA Alkaline Batteries
- 6 VAC/9 VDC Input Hardwired Input Transformer
- 8 second arming delay
- 3 Second Flush Delay

▶ Battery Type

• (4) AA Alkaline

▶ Battery Life

• 3 Years @ 4,000 flushes/month

► Transformers for Hardwire (Sold Separately)

- Sloan Part # EL-386 (Plug-in) 120 VAC Input/ 6 VAC Output, 50/60 Hz (3 VA)
- Sloan Part # EL-451 (Box Mount) 120 VAC Input/ 6 VAC output, 50/60 Hz (25 VA)
- Consult factory for 220/230 VAC Transformer Options

Sensor Range

Self-Adaptive Sensor - Maximum 21" (533 mm)


► Indicator Lights

- Range Adjustment (first 10 minutes)
- Low Battery Warning

▶ Valve Operating Pressure (Flowing)

10-100 psi (0.7-7.0 bars)


▶ OPERATION



 A continuous, invisible light beam is emitted from the infrared sensor.



2. As the user enters the beam's effective range, 9"- 21" (229 mm - 533 mm), the beam is reflected into the Scanner Window to activate the Output Circuit. Once activated, the Output Circuit continues in a "hold" mode for as long as the user remains within the effective range of the sensor.



3. When the user steps away from the sensor, the sensor initiates an electrical signal that operates the Solenoid. This initiates the flushing cycle to flush the fixture. The Circuit then automatically resets and is ready for the next user.

► ROUGH-IN

